


Numark®

Professional Disc Jockey Products

CD MIX-2

PROFESSIONAL CD MIXING CONSOLE



OPERATING MANUAL

Safety Information and Product Registration



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE ANY COVER. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL ONLY.

The lightning flash with arrowhead symbol within the equilateral triangle is intended to alert the user to the presence of un-insulated “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock.

The exclamation point within the equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying this appliance.


CAUTION
FOR USA & CANADIAN MODELS ONLY
TO PREVENT ELECTRIC SHOCK DO NOT USE THIS (POLARIZED) PLUG WITH AN EXTENSION CORD, RECEPTACLE OR OTHER OUTLET UNLESS THE BLADES CAN BE FULLY INSERTED TO PREVENT BLADE EXPOSURE.

SAFETY INSTRUCTIONS


- a) Read Instructions - All the safety and operating instructions should be read before this product is connected and used.
- b) Retain Instructions - The safety and operating instructions should be kept for future reference.
- c) Heed Warnings - All warnings on this product and in these operating instructions should be followed.
- d) Follow Instructions - All operating and other instructions should be followed.
- e) Water and Moisture - This product should be kept away from direct contact with liquids.
- f) Heat - Avoid placing this product to close to any high heat sources such as radiators.
- g) Ventilation - The appliance should be situated so that it’s location or position does not interfere with it’s proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation



opening; or, placed in a built-installation, such as bookcase or cabinet that may impede the flow of air through the ventilation openings.



- h) Power Sources - This product should be connected to a power supply only of the type described in these operating instructions, or as marked on the unit.
- i) Power Cord Protection - Power supply cords should be routed so that they are not likely to be walked upon or pinched by items placed on or against them. When removing the cord from a power outlet be sure to remove it by holding the plug attachment and not by pulling on the cord.
- j) Object and Liquid Entry- Take care that objects do not fall into and that liquids are not spilled into the inside of the mixer.
- k) Cleaning - The appliance should be cleaned only as recommended by the manufacturer.
- l) Non-use Periods - The power cord of the appliance should be unplugged from the outlet when left unused for long periods of time.
- m) Damage Requiring Service - Only qualified personnel should service this product. If you have any questions about service please contact Numark at the number(s) shown on the back cover of this manual.



- n) Grounding or Polarization - Precautions should be taken so that the grounding or polarization means built into the CD player is not defeated.
- o) Internal/External Voltage Selectors - Internal or external voltage selector switches, if any, should only be reset and re-equipped with a proper plug for alternative voltage by a qualified service technician. Do not attempt to alter this yourself.
- p) Carts and Stands - The appliance should be used only with a cart or stand that is recommended by the manufacturer of the cart or stand for this purpose. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.

CD MIX-2

WARNING: To reduce the risk of fire or electrical shock, do not expose this appliance to rain or moisture. Electrical equipment should NEVER be kept or stored in damp environments.

DANGER: INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCK FAILED OR DEFEATED. AVOID DIRECT EXPOSURE TO BEAM.

CAUTION: This product utilizes a laser. Use of controls or adjustments other than those specified herein may result in hazardous radiation exposure.

SERVICE INSTRUCTIONS

1. Disconnect power cord before servicing
2. Replace critical components  only with factory parts or recommended equivalents
3. For AC line powered units - Before returning repaired unit to user, use an ohmmeter to measure from both AC plug blades to all exposed metallic parts. The resistance should be no more than 100,000ohms.

NOTICE CONCERNING FCC REGULATIONS

This equipment generates and uses radio frequency energy and may cause interference to radio and television reception if you do not operate it in strict accordance with the procedures detailed in this OPERATING MANUAL.

This unit complies with Class B computing device rules in accordance with the specifications in Sub-part J or Part 15 of the FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. There is no guarantee, however, that interference will not occur in a particular installation. If the unit does cause interference to any radio or television reception, try to reduce it by one or more of the following means:

- a) Reposition the other unit and/or its antennae
- b) Move this unit
- c) Move this unit and the other unit(s) further apart
- d) Plug this unit into a different AC outlet so that it is on a different circuit from the other equipment.

This note is in accordance with Section 15.838 of the FCC Rules.

This unit does not exceed the Class B limits for radio noise emission from digital apparatus set out in the radio interference regulations of the Canadian Department of Communications.

DOUBLE INSULATED - When servicing use only identical replacement parts

For 220-volt use in USA, use NEMA style 220-volt plug. For other countries use proper plug for local outlet.

Please record the serial number of your unit as shown on the back of the chassis as well as the name of the dealer from whom you purchased the unit. Retain this information and your original purchase receipt for your records. Please return the enclosed warranty card to register your CD player with us.

MODEL: _____
SERIAL NUMBER: _____

PURCHASED FROM: _____
DATE OF PURCHASE: _____

Numark- The Leader in DJ Technology

Numark® CD MIX-2

PROFESSIONAL CD MIXING CONSOLE

CONGRATULATIONS...

You have just purchased a combination dual CD player and mixer designed specifically for the professional DJ. This unit has been designed to provide portable CD mixing with the same ease and creativity that you have enjoyed with records. Please take a few moments to familiarize yourself with the CD MIX-2 by reading the following information before attempting to operate the unit.

Once again, congratulations and thank you for choosing the CD MIX-2.

FEATURES:

CD Section

- Full buffered Anti-Shock™ memory
- Seamless looping (entire CD) with edit function
- Instant stutter start with settable stutter points
- Fader start
- Relay play
- True buffered instant start
- ± 16% pitch bend/jog wheel
- Infinite full CD continuous play
- 3 speed scanning forward and reverse
- Frame accurate search (1/75 sec-step)
- Auto-dead space elimination with auto cue
- Automatic CD tray protection
- +10 tracks skip search
- 30 tracks programmable play
- Enormous backlit display

Mixer Section

- External input for 2 Phono or 3 Line inputs
- Master balanced/unbalanced
- Direct input for onboard CD units
- Input for 2 External Microphones with independent gain control
- Crossfader to blend between 2 Channels and control Auto start of the CD units
- Three band Equalizer for master output
- Dual Band, 12-segment LED output display
- Fader CD Start button
- Headphone output for 1/4" and 1/8" style plugs with the ability to cue any channel
- 12VDC power input to allow car battery usage

CHECK TO BE SURE THE FOLLOWING ITEMS ARE IN THIS BOX:

- (1) CD MIX-2
- (1) OWNERS MANUAL (THIS BOOKLET)
- (1) POWER ADAPTER

TABLE OF CONTENTS

Safety and Registration	2
Introduction	4
Important Information	5
Description of the Features	
CD Player	6
Display	7
Mixer	8
Rear Panel	9
Operation	
Play, Pause and Cue Operations	10
Matching the Tempo	11
Beat Matching Using Pitch Bend	11
Example of Mixing	12
Looping	13
Stuttering	16
Before Switching off the Power	18
Troubleshooting Guide	18
Specifications	19
Warranty	20

IMPORTANT INFORMATION...


Please read this entire manual before connecting this unit to your system.

For optimum performance:

- a) Never use spray cleaners on the slide controls. Residues cause excessive dirt build-up and this will void your warranty. In normal use slide controls can last for many years. If they malfunction (usually because of a dirty or dusty environment) consult a professional technician.
- b) Always make sure that AC power is OFF while making any connections.
- c) Use appropriate cables throughout your system. Do not use excessively long cables (i.e. over 50ft/14m) Be sure plugs and jacks are tightly mated. Loose connections can cause hum, noise or intermittents that could easily damage your speakers. Make the input and output connections with readily available low-capacitance stereo cables. Quality cable makes a big difference in audio fidelity and punch. See your Numark dealer or an electronics or audio specialist store if you are not sure which cables to get.
- d) Never attempt to make any adjustments or repairs other than those described in this manual. Take the unit to your dealer or to an authorized Numark Service Center.
- e) ALWAYS remember: "TURN AMPS ON LAST AND OFF FIRST". Begin with master faders or volume controls on minimum and the amplifier gain/input control(s) down. Wait 8 to 10 seconds before turning up the volume. This prevents transients which may cause severe speaker damage.
- f) Use restraint when operating controls. Try to move them slowly. Rapid adjustments could damage speakers due to amplifier clipping.
- g) Avoid amplifier "clipping" at all costs: this occurs when the red LEDs (usually on the front panel of most professional power amplifiers) start flashing. "Clipping" is when the power amplifier is distorting and working beyond it's limits. Amplifier distortion is THE major cause of speaker failure.
- h) To prevent fire or shock hazard, do not expose the unit to rain or moisture. Never place cans of beer, soda, glasses of water or anything wet on top of the unit!


Numark- The Leader in DJ Technology

DESCRIPTION CD MIX-2 CD PLAYER FEATURES




1. **OPEN/CLOSE (Disc Tray Open/Close)** - Press to load or eject the disc. Each press will open or close the disc tray on the transport. *NOTE: Tray will not open unless the disc has been paused. Tray will automatically close after 30 seconds.*
2. **TIME (Time Button)** - Switches the time display between elapsed playing time and remaining time on the track and remaining time on the entire CD.
3. **CONT/SING** - Will cause just a single track to play or all tracks in order by pressing once or twice.
4. **LCD DISPLAY** - Indicates all the functions, as they are occurring, with the CD. These functions are explained in the next section.
5. **TRACK (Track Buttons)** - Used to select the track to be played.
6. **Track 10 Button** - This button is for quickly advancing to higher tracks on a CD.
7. **PROGRAM** - Depress this button and the unit will stop and the program indicator will light. Select each track to be programmed and press the PROGRAM button between selections. You can program up to 30 tracks. Press PLAY to start the program. To exit and erase program, either hold the program button down for more than 2 seconds while the unit is stopped, open the disc tray, or turn off the power.
8. **PITCH (Pitch Button)** - Activates the Pitch Slider.
9. **PITCH SLIDER** - The pitch can be changed up to +/-12% by pressing the PITCH button so the PITCH LED is lit, then moving the sliding fader. The pitch will not be changed if the PITCH LED is off.
10. **SEARCH WHEEL (OUTER RING)** - 3 forward and 3 reverse speed positions for searching through songs. The more you turn the wheel in either direction the faster you search through the music.
11. **PITCH BEND/JOG WHEEL (INNER RING)** - The jog wheel serves 2 functions depending on the current mode.
 - a) The jog wheel will control a slow frame search when the CD is not playing. To set a new frame cue point, spin the wheel then press play when you have determined the proper position. Press CUE to return to the "CUE POINT".
 - b) When both CD players are playing a CD, the pitch bend function allows the positioning of the bass beats to be matched after the pitch of each disc is matched. Either player can "catch up" or "fall back" to match the other player. The jog wheel will temporarily bend the pitch of the music if the song is already playing by rotating the wheel clockwise to speed up or counterclockwise to slow down. By changing the pitch of one disc with respect to the pitch of the other disc, the beats can be matched.
12. **CUE** - Pressing the CUE button during play provides a return to the position at which play was started. If PAUSE is used before CUE, that will become the cue point. Alternately pressing the PLAY button and the CUE button allows the CD to be played from the same position any number of times. The CUE LED will light up from the time the CUE button is pressed until the CD has been reset to the position at which play was started. Steady lighting of this LED indicates the ready condition.
13. **START/PAUSE (Play/Pause Button)** - Each press of the Play/Pause Button causes the operation to change from play to pause or from pause to play.
14. **LOOP IN** - Used for setting a start loop point and new cue points during play.
15. **LOOP OUT** - Used for setting the end loop point and releasing the loop action.
16. **RELOOP/STUTTER** - Depending on mode, as explained further, this button is used for either repeating a previously set loop or seamlessly stuttering on the last set cue point.

LCD DISPLAY FEATURES




1. **PLAY** - Active while the unit is actually playing a CD.
2. **PAUSE** - Active when the unit is paused.
3. **CUE** - Flashing when the unit is setting a cue point. Lit continuously when the unit is paused at a cue point.
4. **PROGRAM** - Used for pre-programming the track order to automatically be played by the unit. This is a great function if you need to leave the CD player alone.
5. **TIME MODE** -
(Elapsed) is for showing time as it is taking place.
(Remain) shows how much time is left on a particular track. This function is controlled by the TIME BUTTON.
6. **SINGLE** - Shows when the unit is set to play just one track at a time. When this is not lit, the CD will play continuously through all tracks. This function is controlled by the SING/CONT BUTTON.
7. **PITCH** - Is lit when the PITCH BUTTON is active.
8. **TIME BAR** - Shows either time remaining or elapsed depending on the setting of the TIME BUTTON.
9. **PITCH** - Shows the percentage change in pitch.
10. **TRACK** - Shows the current track that the unit is playing.
11. **MINUTES** - Shows the minutes elapsed or remaining depending on mode setting.
12. **SECONDS** - Shows the seconds elapsed or remaining depending on mode setting.
13. **FRAMES** - The CD Player breaks down a second into 75 frames for accurate cueing. This shows the frames elapsed or remaining depending on mode setting.
14. **LOOP** - Indicates when loop is actively playing
15. **RELOOP** - Indicated when "LOOP IN" and "LOOP OUT" have been set and a loop is available for play.

MIXER FEATURES



1. **Input fader** - Controls individual source levels in the mix
2. **Input toggle switch** - Selects which source will be live to that channel based on what you have connected to the rear panel input section. In CD position the internal CD units are active.
3. **2-Band Stereo Equalizer (EQ)** - compensates for differences in source material sound quality.
4. **Replaceable Crossfader** - Achieves clean segues between the two input channels. "Hard left" selects Channel 1. "Hard right" selects Channel 2. With the crossfader centered, both assigned channels are live. Use the crossfader for fast and seamless segues from one selected channel to the other
Note: The crossfader is user replaceable in case of failure. Simply unscrew the two large screws which hold it in place, lift it out and disconnect it's cable. Re-attach the new crossfader and screw the mounting plate back onto the unit - you're back in business!
5. **Fader Start** – Activation allows you to start the CD players from you crossfader. Travel from left to right will start the right CD player and pause the left CD player
6. **Mic 1 Input Fader** – Adjusts microphone level
7. **Mic 1 Equalizer (EQ)** – adjusts microphone 1 treble and bass levels.
8. **Master Stereo EQ** – Adjust final master output equalization of treble, middle, and bass
9. **Master Fader** - Controls the overall output level
10. **Stereo/Mono toggle** - Changes the Master output between Mono and Stereo
11. **LED Meter** - Indicates the Master output level
12. **Channel Monitor Selector** - Used to route channel audio to your headphones for cueing
13. **Cue Mix Control** – adjusts the headphone blend of master output (PGM) and monitor (CUE) sound.
14. **Headphone Level** – Adjusts cue volume
15. **Headphone Jacks** – Used to connect either 1/8" or 1/4" plugs for audio monitoring with headphones


REAR PANEL FEATURES



1. **Channels Inputs** - Unbalanced RCA jacks for connecting external sources. The Phono/Line Input is selected with the toggle switch on the front panel. You can connect stereo audio from Turntables, HiFi VCRs, cassette and reel-to-reel tape decks, DAT machines, CD players, laser discs, tuners, even synthesizers or other mixing consoles.
NOTE: Plug mono audio sources into both Left and Right inputs using a "Y" cable connector.
2. **GND** - Grounding lug for turntable connection. Always use this connection when using turntables. (your turntable cable should have a grounding wire)
3. **Line/Phono Input switch** - Use this to allow either line level or phono level equipment to be plugged into your channel inputs. When Phono input is selected, your signal is fed directly to the high-quality RIAA phono pre-amplifiers. Use this position only for turntables. Line level sources will overload the sensitive phono pre-amps and will sound very bad, so always be sure to toggle the line/phono switch over to line before connection of line sources.
4. **Third Line Input** – Plug in a third line level device such as tape deck or additional CD player here.
5. **Stereo Main Outputs** - Unbalanced RCA connectors controlled by the **Master** fader.
6. **Balanced Main Outputs** - Low-impedance XLR type connectors controlled by the **Master** fader.
7. **Mic Input** – Plug your 1/4" Microphone plug in here.
8. **Power Connector** - Plug in power adapter here and check the voltage level to match your country's standard.
9. **Power Switch** – Turn on unit here.


DESCRIPTION OF THE PLAY/PAUSE AND CUE OPERATIONS

PLAY and CUE



Pressing the "PLAY/PAUSE" button starts the disc. Pressing the "CUE" button will reset the disc to the last place where the disc was started. This is called the cue point. By alternately pressing the "PLAY/PAUSE" button and the "CUE" button, the disc may be returned and played from the cue point any number of times. This function is called "back cue".


PLAY, PAUSE and CUE



When play has been paused and then started again, the return position for the back cue will be updated to this new position.


EDITING CUE POINT

When the inner search dial is turned while a cue point is set, a new cue point can be located. The CD player will repeatedly play small parts of the CD as you move it to the desired position. By pressing "PLAY/PAUSE" then "CUE" you can confirm that this new cue point is desirable.



MATCHING THE BEATS PER MINUTE (BPM)

Match the tempo by monitoring the music of both PLAYER 1 and PLAYER 2 by ear and adjusting the pitch. When the tempo of the music of the selected CD player is slow compared to the tempo of the other player, move the slider to the (+) side and match the tempo. When faster, move the pitch slider to the (-) side. The following illustration shows the case of matching the pitch of PLAYER 2 to the pitch of the music being played on PLAYER 1.




BEAT MATCHING USING PITCH BEND


If you find the BPM's (Beats Per Minute or Tempos) are the same, however, the drum beats are not matched you will need to temporarily change the pitch. The illustration below shows how to match the beat of PLAYER 2 to the beat of the music being played on PLAYER 1. (This procedure can be done on either PLAYER).

After matching the BPM's adjust the pitch temporarily as follows:

When PLAYER 2 is rotate the jog wheel counter clockwise



When PLAYER 2 is behind rotate the jog wheel clockwise




The pitch changes automatically while the jog wheel is rotated. The faster you rotate the wheel the more you change. Releasing the wheel results in a return to the original pitch. (So the BPM's are once again the same.)


EXAMPLE OF MIXING USING BOTH PLAYERS OF YOUR CD PLAYER

While playing a disc on PLAYER 1, load a disc into PLAYER 2 and select your next track, match its pitch to the track playing on PLAYER1 and when you are ready use the crossfader on your mixer to fade from PLAYER 1 to PLAYER 2.


Load a disc in PLAYER 1 and select the track and press PLAY.



Load a disc and press the OPEN/CLOSE button.




Select the track to be played.




Press the PLAY button


Load a disc in PLAYER 2 and select the track then play.



Load a disc and press the OPEN/CLOSE button.




Select the track to be played.




Press the PLAY button


Set and edit a start cue point on PLAYER 2



Press the Pause button of PLAYER 2.




Rapidly search for a cue point using the outer wheel




Slowly set the right cue point using the inner wheel


Check you new cue point



Listen with the monitor and press the play button.




Press the cue button then play to be sure of the set cue point.




Reset the player to the Cue point by pressing Cue


Do a MIX!



With a matching downbeat from Player 1 press the play button.



If you are beat mixing, turn on your Pitch adjust and follow the directions for beat matching.




When you are happy with your mix the crossfader accordingly.

USING THE LOOPING FEATURES


These features are for seamlessly looping certain areas of the CD. A loop is any area of a CD that you choose to repeat with no breaks.

There are 3 buttons associated with the loop feature.



LOOP IN


The "LOOP IN" is where you wish for the loop to actually start. You will notice the "LOOP IN" LED will be lit every time you put in a new CD and select a new track. This means that the initial "CUE" point of the CD is also the default "LOOP IN" point. If you wish to set a new "LOOP IN" point, just press the "LOOP IN" button while the CD is playing when it reaches the desired point. *By default this also becomes the new "CUE" point.*



NOTE: The CD Player will always remember a new set point as the "LOOP IN" point until you actually set a new "LOOP IN" point, erase the loop, or put in a new CD. If you set a "LOOP IN" point and then do a track search prior to the point position, thus setting a new auto-cue point, the LOOP IN LED will turn off. This indicates that the CD player has stored a "LOOP IN" point but the point is not accessible until the CD player plays through the "LOOP IN" point. The "CUE" button will return you to the start position until you play through the "LOOP IN" point. Then it will return to "LOOP IN"

LOOP OUT

The "LOOP OUT" determines the end point for a loop. The first time you press this button while a CD is in play mode, the "LOOP OUT" LED will turn on and flash while the song automatically returns to the "LOOP IN" point with no breaks and continues to play. When the song reaches the "LOOP OUT" point again it returns to the "LOOP IN" point and continues to repeat this action. You will notice the "LOOP IN" LED will also be flashing during loop action. To release or end the LOOP press the "LOOP OUT" button a second time and play will continue forward when the song passes the previously set "LOOP OUT" point. The "LOOP OUT" and "LOOP IN" LEDs will also be lit solid indicating that these "LOOP" points are now in memory for "RELOOP" purposes.




Note: The "LOOP OUT" point will be erased if "LOOP IN" is pressed or a new "CUE" point is set after the "LOOP OUT" point. This is important because without this point "RELOOP" will not be possible


MOVING LOOP POINTS

The "LOOP IN" point can be moved while a loop is playing just by pressing the "LOOP IN" button at the new desired point. The next time "LOOP OUT" is reached the CD will return to this new "LOOP IN" point. If you should accidentally set a new "LOOP IN" point at the same place as your "LOOP OUT" point the "LOOP OUT" point will be erased and play will continue.

Note: If for any reason you should press pause then play to restart a track in between these loop points, setting a new cue point, this will also set a new "LOOP IN" point.




The "LOOP OUT" point can also be moved while a loop is playing just by first pressing this button to release the old "LOOP OUT" point and pressing it again at the new desired point.



RELOOP

The "RELOOP/STUTTER" button performs 2 different functions depending on your state of play. The Reloop function is possible only if "LOOP" points have been previously set and the CD is playing beyond the "LOOP OUT" point.

The "RELOOP" button automatically causes a loop to be played again until it is released with the "LOOP OUT" button. The LEDs will flash during the loop and then become solid following the loop.



The second function of this button is described in the section called "STUTTERING FUN"

PRE-PROGRAMMING AND EDITING A LOOP

LOOP IN PRE-PROGRAM

To pre-program your "LOOP IN" point either play your song or search for the desired "LOOP IN" point using the search and jog wheels. When you get to the desired point press "LOOP IN". If you wish to edit this point turn the jog wheel until you find the desired point. When you press play the CD will begin play from the new "LOOP IN" point. This also is the *temporary* new "CUE" point. If you then hit play to listen to the point and cue to go back you can continue to edit with the jog wheel.

LOOP OUT PRE-PROGRAM

To pre-program your "LOOP OUT" point play your song until you get to the desired "LOOP OUT" point and press "LOOP OUT". To rapidly advance over a long distance you can use the search wheel with no center cue-jog. **DO NOT USE THE TRACK BUTTONS****. If the CD player is presently in play mode, the song will return to the "LOOP IN" point and continue playing the LOOP.

If you wish to precisely set the "LOOP OUT" point while searching;

- press "PAUSE" once only before you reach the desired point, if you are currently in play.
- turn the jog wheel until you find the desired point.
- hit "LOOP OUT" .

REVIEW YOUR LOOP

To review, press "RELOOP" only and the CD will begin playing the LOOP from the "LOOP IN" point so you may listen to the entire LOOP. **DO NOT PRESS PLAY OR YOU WILL SET A NEW "CUE" AND "LOOP IN" POINT AND ERASE THE "LOOP OUT" POINT!** If you wish to advance quickly through a long loop, use the search wheel only.

If you wish to edit this point again;

- Press "LOOP OUT" to release the loop.
- Repeat the above steps.

To review your loop while the CD is already playing press "CUE". This returns the CD to the "LOOP IN" point, then press play.

**** Pressing the track buttons puts the CD player into an auto-cue mode. Multiple tracks are often found for single songs on remix service CDs. The track select mode automatically sets new cue points and would set a new "LOOP IN" point if set after the original "LOOP IN" point.**

PLAYING YOUR LOOP

To return to the beginning of the song and play after you are happy with the loop:

- Press "PAUSE" to stop the play action of the CD or "CUE" to return to the "LOOP IN" point.
- Track backwards until you reach the beginning of the song. (*Remix CD's often contain multiple track numbers for the same song.*)
- Auto-cue to the beginning of the track will then occur. Once this occurs your cue button will return you to this point until you pass over the "LOOP IN" point. Then "LOOP IN" will be the new "CUE" point.
- The "LOOP OUT" LED will be flashing indicating a preset loop is ahead and will be played when reached.
- When the "LOOP IN" point is reached both "LOOP IN" and "LOOP OUT" LEDs should flash.
- The LOOP should occur as preset by you until you release it with the "LOOP OUT" button.
- Both "LOOP IN" and "LOOP OUT" LEDs should then go solid again indicating the possibility of RELOOP.

NOTE: If you should decide that you do not want to automatically play a preset loop after you start a song, just press "LOOP OUT" anytime before you actually reach the "LOOP OUT" point and the "LOOP OUT" LED will remain solid. (You can press it again before the "LOOP IN" point if you change your mind.) The "LOOP IN" LED will come on solid when this point is reached indicating the possibility of RELOOP. This will allow you to use the selection for reloop purposes. However, until you pass the "LOOP OUT" point the "RELOOP/STUTTER" button only acts as a STUTTER function as explained in STUTTERING FUN.

If you turned off your "LOOP OUT" while practicing your loop, remember to turn it on again before reaching the "LOOP IN" point.

ERASING YOUR LOOP

To erase presets loop either;

- Open and close the door.
- Press the program button twice.
- Select a track, a new "CUE" point, or new "LOOP IN" point beyond the "LOOP OUT" point.
- Press "LOOP IN" prior to the old point to set a new loop.

DESCRIPTION OF LED DISPLAY

LOOP IN on /LOOP OUT off: This means that there is a LOOP IN point available for looping and stuttering, but no LOOP OUT point is set yet.

LOOP IN flashing /LOOP OUT flashing : This indicates that the CD player is actively looping from LOOP IN to LOOP OUT.

LOOP IN on /LOOP OUT on: This indicates that the LOOP IN and LOOP OUT points are set and a RELOOP will return to the LOOP IN to play the loop.

LOOP IN off /LOOP OUT off : This indicates that:

- There is a LOOP IN point stored into memory, but this looping function and this STUTTER point are disabled until the music plays through the point.
- There is no LOOP OUT point set yet.

LOOP IN off /LOOP OUT on: A future loop has been stored into memory. This loop will be inactive until either LOOP OUT is pressed prior to the CD playing through the LOOP IN point or RELOOP is pressed after the LOOP IN point.




LOOP IN off /LOOP OUT flashing : An active loop is stored into memory and will automatically play after the music plays through the LOOP IN point.

DESCRIPTION OF STUTTERING FFFFUN.....

This function allows music to be replayed from the last set cue point seamlessly.

Carefully read all of the following conditions to fully understand this button's operation. Don't forget this button serves two functions depending upon the CD player's state of play.

- If the CD is paused either at the beginning of a track or at some other "CUE" point the "STUTTER/RELOOP" can start play of the song and actually seamlessly restart every time the button is pressed.
- If the song is already playing and no additional cue or loop in points have been set then the CD will return to the place where you originally started playing and seamlessly start playing again. If this was on a beat this would be a quick way to seamlessly extend a mix.
- If another "CUE" or "LOOP IN" point has been set, but you have not reached this point yet, the song will return to the start position and seamlessly restart playing.
- If a "LOOP IN" point but no "LOOP OUT" point has been set and you have passed this point, then the song will return to the "LOOP IN" point and start playing. The reason for this is that every time you set a "LOOP IN" point you are also resetting the "CUE" point.
- If a "LOOP IN" point and "LOOP OUT" point have been set, and the CD is in the middle of playing a loop, then the "STUTTER/RELOOP" button will create a stutter back to the "LOOP IN" point and continue the set loop until the "LOOP OUT" button is pressed, to release the loop.
- **Again it is important to remember that "STUTTER" and "RELOOP" are the same button.**
- If a "LOOP IN" point and "LOOP OUT" point have been set and the CD is finished playing a loop then the "STUTTER/RELOOP" will return to the "LOOP IN" and continue to RELOOP until the "LOOP OUT" is pressed.
- If a new "LOOP IN" point is set after the last "LOOP OUT" point then this can be a new "STUTTER" point.




Simply put, you can Stutter on either your initial cue point or a set "LOOP IN" point, whichever is immediately prior to your current play position.

(PRACTICE ALL OF THIS BEFORE SHOWING YOUR SKILLS TO THE AUDIENCE!)

BEFORE SWITCHING OFF THE POWER:

When you have finished using the CD player, be sure that the disc tray is closed with the "OPEN/CLOSE" button before switching off the power.



DO NOT switch off the power when the disc holder is open.

TROUBLESHOOTING:

Symptom	Possible Cause	Corrective Action
The power fails to switch on when the POWER switch is set to on	Poor power plug connection at the AC outlet or IEC Power cord loose from rear of unit	Insert the power plug firmly into the AC outlet and make sure connection is good in unit rear
Disc play does not start	The disc is loaded upside down The disc is too dirty	Reload the disc with the label side up Clean the disc
No sound	Improper output cable connections Improper amplifier operation	Connect the output cables correctly Check amplifier setup
Sound skips	The CD player is still subject to vibrations or physical shock The disc is too dirty	Change the installation location Clean the disc
Programmed disc play will not function	The CD player is in normal disk play mode	Hold down the Program button for 3 seconds then program the tracks
Hum	Loose cable connections	Firmly connect all audio plugs

TECHNICAL SPECIFICATIONS

CD Players

Quantization	16-bit linear/channel, 3 beam laser
Oversampling rate	8 times
Frequency response	20Hz-20KHz
Channel separation	86dB
T.H.D. + NOISE	0.01%
S/N ratio (IHF-A)	94dB
Output level	2.0Vrms
Short access time	
(Play next track)	less than 1.7sec
Long access time	
(Track 1 ->Track 20)	less than 3sec
Instant start	less than .015 sec
Pitch control range	+/-12%
Pitch bend	+/-16%

Overall

Input level/Impedance

Line	-11dBV (280mV)/47K OHM
Phono	-50dBV (3mV)/47K OHM
Mic	-62dBV (0.8mV)/3K OHM

Output level/Impedance

ITEM	0dBV OUTPUT	NON-CLIP MAX
Master (RCA)	0dBV (1V) /1K OHM	+14dBV (5V)
Master (XLR)	3.7dBm (1.2V) /470 OHM	+14dBV (5V)
Headphones (32 OHM)	-18dBV(0.13V) /33 OHM	1V (30mW)

NOTE: 0dBV=1Vrms, 0dBm=0.775Vrms.

Frequency Response

CD	20 - 20KHz	+1,-2dB
Line	20 - 20KHz	+1,-1.5dB
Phono	20 - 20KHz	+2,-2.5dB/RIAA
Mic	33 - 15KHz	+1,-3dB

S/N Ratio: (IEC-A Weighted)

CD/Line	more than 85dB
Phono	more than 75dB
Mic	more than 70dB

Total Harmonic Distortion

CD/Line	less than 0.05%(20KHzLPF)
Phono	less than 0.12%
Mic	less than 0.12%
Headphones (32 OHM)	less than 0.25%

Crosstalk

CD	more than 60 dB at 1KHz
Line/phono	more than 55 dB at 1KHz

Equalizer

Low	+/- 12 dB (100Hz)
Mid	+/- 12 dB (1KHz)
Hi	+/- 11.5 dB (10KHz)

Numark®

Professional Disc Jockey Products

LIMITED PRODUCT WARRANTY

What is covered and for how long?

1. NUMARK INDUSTRIES LCC ("NUMARK") warrants to the original purchaser that NUMARK products; including but not limited to DJ mixers, amplifiers, CD players, CD Mix Stations, turntables, preamplifiers, beatkeepers, equalizers, microphones, headphones, cartridges, and all other accessories; are to be free from defects in material and workmanship under normal use and service for the period commencing upon the date of purchase from an authorized NUMARK dealer for a period of (1) Year.

What is not covered? This Limited Warranty is conditioned upon proper use of the product by the purchaser.

2. This Limited Warranty does not cover: (a) defects or damage resulting from accident, misuse, abuse, neglect, unusual physical or electrical stress, modification of any part of the product, or cosmetic damage; (b) equipment that has the serial number removed or made illegible; (c) all plastic surfaces and other externally exposed parts that are scratched or damaged due to normal use; (d) defects or damage from improper testing, operation, maintenance, installation, adjustment, or service of the mixers; (e) crossfaders.
3. What are NUMARK'S obligations? During the applicable warranty period, NUMARK will repair or replace, at NUMARK'S sole discretion, without charge to the purchaser, any defective component part of the mixer. To obtain service under this Limited Warranty, purchaser must first contact NUMARK and obtain a return authorization number ("RA#"). Purchaser must then return the mixer to NUMARK in an adequate container for shipping, accompanied by purchaser's sales receipt or comparable proof of sale showing the date of purchase, the serial number of the product, and the seller's name and address. To obtain an RA# and assistance on where to return the mixer, contact NUMARK customer service at 401-295 9000. Upon receipt, NUMARK will repair or replace the defective products. NUMARK may, at NUMARK'S sole discretion, use rebuilt, reconditioned, or new parts or components when repairing any product or replace a product with a rebuilt, reconditioned or new product. Repaired mixers will be warranted for a period equal to the remainder of the original Limited Warranty on the original mixer or for (90) days, whichever is longer. All replaced parts, components, boards and equipment become the property of NUMARK. If NUMARK determines that any mixer is not covered by this Limited Warranty, purchaser must pay all parts, shipping, and labor charges for the repair or return of such mixer.
4. What are the limits on NUMARK'S liabilities? THE WARRANTIES GIVEN IN THIS LIMITED WARRANTY, TOGETHER WITH ANY IMPLIED WARRANTIES COVERING NUMARK MIXERS, INCLUDING WITHOUT LIMITATION ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, NUMARK SHALL NOT BE LIABLE FOR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL, INDIRECT OR SIMILAR DAMAGES, LOSS OF PROFITS, DAMAGES TO PURCHASER'S PROPERTY, OR INJURY TO PURCHASER OR OTHERS ARISING OUT OF THE USE, MISUSE OR INABILITY TO USE ANY NUMARK MIXER, BREACH OF WARRANTY, OR NEGLIGENCE, INCLUDING BUT NOT LIMITED TO NUMARK'S OWN NEGLIGENCE, EVEN IF NUMARK OR ITS AGENT HAS BEEN ADVISED OF SUCH DAMAGES, OR FOR ANY CLAIM BROUGHT AGAINST PURCHASER BY ANY OTHER PARTY. THIS LIMITED WARRANTY IS THE COMPLETE WARRANTY FOR NUMARK'S MIXERS, AND IS GIVEN IN LIEU OF ALL OTHER EXPRESS WARRANTIES. THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT AND STATES PURCHASER'S EXCLUSIVE REMEDY. IF ANY PORTION OF THIS LIMITED WARRANTY IS ILLEGAL OR UNENFORCEABLE BY REASON OF ANY LAW, SUCH PARTIAL ILLEGALITY OR UNENFORCEABILITY SHALL NOT AFFECT THE ENFORCEABILITY OF THE REMAINDER OF THIS LIMITED WARRANTY WHICH PURCHASER ACKNOWLEDGES IS AND WILL ALWAYS BE CONSTRUED TO BE LIMITED BY ITS TERMS OR AS LIMITED AS THE LAW PERMITS.
5. This Limited Warranty allocates risk of product failure between purchaser and NUMARK, and NUMARK'S product pricing reflects this allocation of risk and the limitations of liability contained in this Limited Warranty. The agents, employees, distributors, and dealers of NUMARK are not authorized to make modifications to this Limited Warranty, or make additional warranties binding on NUMARK. Accordingly, additional statements such as dealer advertising or presentation, whether oral or written, do not constitute warranties by NUMARK and should not be relied upon.
6. How does state law apply to this warranty? SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATIONS OF INCIDENTAL OR CONSEQUENTIAL DAMAGES OR HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO PURCHASER.
7. This Limited Warranty gives you specific legal rights. You may also have other rights, which vary from one jurisdiction to another.

RETURN INFORMATION

- c) A Return Authorization number must be obtained from Numark through the address or phone numbers below.
- d) A copy of the original sales receipt must also be included for the equipment to be repaired under warranty.
- e) The faulty equipment must be packed in its original packaging.
- f) One additional outer layer of packaging must be included to ensure product safety. Failure to do so may inadequately protect the equipment in transit and, therefore, jeopardize the customer's warranty.
- g) Numark will not accept COD shipments and no call tags will be issued for merchandise return.
- h) Numark will not return repaired merchandise to customers by priority service, unless by written request at the customer's cost. Requests must be submitted in writing with merchandise returned.
- i) The defective Numark equipment should be sent, FREIGHT PREPAID with Return Authorization number clearly printed on the outer packaging and original sales receipt enclosed to:

Numark INDUSTRIES
Attention: Service Department
11 Helmsman Avenue
North Kingstown, RI 02852 USA

Phone: +1 (401) 295-9000
Fax: +1 (401) 295-5200
Web: www.numark.com